



# PowerTel 500

## User Guide



<b>User Guide</b> .....	<b>1</b>	<b>Changing Clock Settings</b> .....	<b>17</b>
<b>Safety Information</b> .....	<b>4</b>	<b>Changing Base Settings</b> .....	<b>18</b>
<b>Getting Started</b> .....	<b>6</b>	<b>Phone Book</b> .....	<b>19</b>
<b>Set Up</b> .....	<b>6</b>	<b>Adding a Handset</b> .....	<b>25</b>
<b>Handset Display Icons</b> .....	<b>8</b>	<b>Help and Support</b> .....	<b>32</b>
<b>Phone Menu and Display Guide</b> .....	<b>9</b>	<b>Troubleshooting Guide</b> .....	<b>32</b>
<b>Calling Functions</b> .....	<b>10</b>	<b>Technical Details</b> .....	<b>34</b>
<b>Menu Options</b> .....	<b>14</b>	<b>Default Settings</b> .....	<b>35</b>
<b>Changing Menu Settings</b> .....	<b>16</b>	<b>Maintenance and Warranty</b> .....	<b>36</b>

## FCC Compliance



The FCC requires that you will be advised of certain requirements involving the use of this telephone.

1. This equipment complies with Part 68 of the FCC rules. A label on the base unit of this equipment contains, among other information, the ACTA Registration Number (US:AAAEQ#TXXXX) and the Ringer Equivalence Number (REN) for this equipment. You must, upon request, provide this information to your telephone company.
2. An applicable certification jacks Universal Service Order Codes (USOC) for the equipment is provided (i.e., RJ11C) in the packaging with each piece of approved terminal equipment.
3. A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.
4. The REN is useful to determine the quantity of devices you may connect to your telephone line and still have all of those devices ring when your number is called. In most, but not all areas, the sum of the REN of all devices should not exceed five (5.0). To be certain of the number of devices you may connect to your line, as determined by the REN, you should call your local telephone company to determine the maximum REN for your calling area.  
NOTICE: If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this equipment does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.
5. If your telephone causes harm to the telephone network, the telephone company may discontinue your service temporarily. If possible, they will notify you in advance. But if advance notice is not practical, you will be notified as soon as possible. You will be advised of your right to file a complaint with the FCC.
6. Your telephone company may make changes to its facilities, equipment, operations or procedures that could affect the proper operation of your equipment. If they do, you will be given advance notice so as to give you an opportunity to maintain uninterrupted service.
7. If you experience trouble with the telephone, please contact the Amplicom Service Center at 1-866-AMPLICOM (267-5426) for repair/warranty information. The telephone company may ask you to disconnect this equipment from the network until the problem have been corrected or you are sure that the equipment is not malfunctioning.
8. This equipment may not be used on coin service provided by the telephone company. Connection to party lines is subject to state tariffs. (Contact your state public utility commission or corporation commission for information.)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Privacy of communications may not be ensured when using this phone. Changes or modifications not expressly approved in writing by Amplicom may void the user's authority to operate this equipment.

Some cordless phones operate at frequencies that may cause interference to nearby TVs and VCRs; to minimize or prevent such interference, the base of the cordless phone should not be placed near or on top of a TV or VCR; and, if interference is experienced, moving the cordless telephone farther away from the TV or VCR will often reduce or eliminate the interference.

# PowerTel 500 Cordless handset and base



- 1 Memory 1
- 2 35dB Boost
- 3 Enter Menu/  
Mute/Delete
- 4 Internal call
- 5 External call/  
Handsfree
- 6 \*Ringer on/off
- 7 Pause  
(long press 0)
- 8 Volume up/down
- 9 Memory 2
- 10 Up/Redial
- 11 Headset socket
- 12 Phonebook/  
Save/OK
- 13 Recall
- 14 End call
- 15 Down/Calls list/  
Equalizer
- 16 Keypad
- 17 #/Keylock
- 18 Find handset/  
Registration
- 19 Incoming call/  
Boost light

(Headset not included)



**Warning:** This Handset has been specially designed for individuals who are hard of hearing and has a normal volume which is louder than a standard phone. Use of the Boost feature can cause hearing damage to individuals who are not experiencing hearing loss.

## Important Safety Instructions

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

1. Do not use this product near water, for example, near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
2. Do not use the telephone to report a gas leak in the vicinity of the leak.
3. Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions. Save these instructions for future use.

### SAVE THESE INSTRUCTIONS

## Intended use

This phone is suitable for use on a public telephone network. Any other use is considered unintended use. Unauthorized modification or reconstruction is not permitted. **Do not** open the device and attempt any repair work yourself.

## Phone location

Locate the base:

- On a dry, flat and stable surface
- Where the power cable will not be a trip hazard
- Where it is not obstructed by furniture

- At least three feet from other electrical appliances
- Away from smoke, dust, vibration, chemicals, moisture, heat or direct sunlight.

## Power failure – What to do

This telephone cannot be used to make calls in the event of a power failure. Alternative arrangements should be made for access to emergency services.


## Medical equipment

Do not use the phone near emergency or intensive care medical equipment, or during an electrical storm. If you have a pacemaker check with a medical expert before using this product.

## Hearing aid compatibility

This phone works with most popular hearing aids. However, given the wide range of hearing aids available, the phone may not function fully with some hearing aid.

Telephones identified with this logo have reduced noise and interference when used with most T-coil equipped hearing aids and cochlear implants. The TIA-1083 Compliant Logo is a trademark of the Telecommunications Industry Association. Used under license.





**Caution: The phone will produce high volume when Boost is switched on.**

## Getting Started — Included Equipment


- 1 Base
- 1 Cordless Handset
- 1 Battery Cover
- 1 Belt Clip
- 1 Power Adapter
- 1 Telephone Cable
- Rechargeable AAA 2.4V 750mAh NiMH Battery Pack

## Set up

### 1. Connect base

- Plug the power adapter into the socket marked  on the back of the phone base and the other end into a wall socket.
- Plug the telephone cable into the  socket on the back of the phone base.


**Do not connect phone line to the phone wall socket yet.**



**Important: Use only Power supply model S008CU120067 supplied by Ten Pao Industrial Co., Ltd. for Base unit.**

## 2. Install battery pack

Insert the rechargeable battery pack into the handset and plug it in as shown. Dispose of battery pack properly. Do not allow battery pack to come into contact with fire or water.



**Caution: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.**

## 3. Charge handset

Place the handset on its base to charge for a minimum of 15 hours before use.

**Important: Only use the rechargeable battery pack model GPHCH73N07, 750mAh NiMH supplied by GPI INTERNATIONAL LIMITED.**

## 4. Connect telephone cable

After initial charge, plug the telephone cable into the telephone wall socket.

## 5. Attach belt clip (optional)

Slide the belt clip into the two holes located on either side of the handset.

**Your PowerTel 500 is now ready for use!**

# Handset Display Icons

The following icons can appear in the handset display:



Menu



Previous menu



Confirm / OK



Phone book mode



More information to view left



More information to view right



Battery status



Ringer off



Keylock is on



Handsfree mode



Call in progress



Boost receiver volume is on  
(Icon will flash)



Mute handset microphone



New calls



When steady— handset is in  
range



When flashing — handset  
is out of range





Internal call in progress (if  
additional handsets are  
installed)





# Phone Menu and Display Guide




The phone menu display allows access to the full phone functionality.

**Open main menu:** Press .

**Browse sub menu:** Open the main menu and then press /P or /R.

**Select sub menu item:** Scroll using /P or /R until the menu item desired is highlighted and press .

**Browse a function:** Open the sub menu and press /P or .

**Select a function:** Scroll using /P or /R until the required function is highlighted and press .

**Enter digits or letters:** Use the keypad.



**Confirm or save an entry or action:** Press .

**Cancel and return to standby:** press .

**Note:** After 20 seconds, the phone will go into standby mode unless a button is pressed.

# Calling Functions


## Make a call

1. Enter the phone number.
2. Press  to delete a mistaken entry.
3. Dial the number by pressing .

## End a call





Press .

## Answer a call

1. Lift the handset off the base and speak into the phone.
2. If the handset is off the base, press  and then speak into the phone.





## Redial a number

The phone stores the last 10 numbers dialed.





1. Open the redial list by pressing .
2. Scroll through the redial list using  or  until the desired number to redial is highlighted and press .

## Call back a previous caller




The phone stores the last 30 incoming phone numbers.

1. Open the incoming calls list by pressing .
2. Scroll to find the desired number using /P or , press .

## Dial a number in the phone book

1. Open the phone book by pressing .
2. Scroll to find the desired number using /P or , press .

## Dial a number using the quick dial buttons


1. Choose a quick dial number by pressing  or .
2. Press  to dial the number.

## Adjust the handset earpiece volume

Note: The handset earpiece volume is louder than a standard phone.





To adjust the volume during a call, push the button on the side of the handset up or down.

## Boost the handset earpiece volume

To boost the handset earpiece volume during a call, press the  key on the top left side of the handset. An image of an ear will flash in the display and the light on the top of the handset will be lit to show that boost is on.

## Handsfree feature

Use the handsfree feature to talk to the caller without holding the handset or to let other people in the room listen to the conversation.

1. Switch on handsfree mode during a call by pressing the  key twice.
2. Exit handsfree mode by pressing .
3. To adjust the handsfree volume, use the switch on the right of the handset or the  or  buttons.

**Note:** Boost volume using   is not available during handsfree calling.

## Use a headset (not included)

Plug a headset into the headset socket on the right side of the handset.

## Mute the phone

Muting the phone during a call will silence the mouthpiece on the phone so it does not transmit any noise to parties on the other end of the line.

To switch off the mouthpiece, press . **Mute On** will be displayed.





To switch it on again, press . The display will show **Off**.

## Switch the handset ringer on and off

To switch the ringer on and off, press and hold  for five seconds.



## Lock and unlock the handset keypad

Calls can still be answered as usual when the keypad is locked.

1. To lock the keypad, press and hold  for 2 seconds. The  icon will be displayed.
2. To unlock, press and release  then immediately, press and release .

## Find handset

A missing handset can be located from the base.

1. Press  on the base. The handset(s) will beep.
2. Press  on the base again or any button on the handset to stop the handset(s) beeping.

# Menu Options













## Priority/Default Setting

Any changed settings in the menu will be saved as default. The phone also allows for two separate user profiles.














## User Profiles


The phone can store 2 different user profiles with different settings for the Volume, Boost, and Equalizer features. Each Profile can be given a personalized name.

## Change a profile name

1. Open the menu by pressing , scroll using  or  until **Profile** is highlighted and press .
2. Scroll using  or  until **Profile 1 or 2** is highlighted and press .
3. Scroll using  or  until **Name** is highlighted and press .
4. Delete the current name by pressing .
5. Enter a new name (up to ten letters) and press .





## Change a profile's handset Volume or Equalizer

1. Open the menu by pressing , then scroll using  or  until you highlight **Profile** and press .
2. Scroll using  or  until **Profile 1** or **2** is highlighted, press .
3. Scroll using  or  until the desired setting is highlighted, press .
4. The current setting will be displayed.
5. Change the appropriate setting using  or  and press .

**Note:** Press  to exit the menu and return the handset to standby.

## Choosing which profile to use

Note: Handset must be used to choose a profile for a call – a profile cannot be chosen using handsfree.

1. Before answering an incoming call, press  or .
2. The display will confirm your choice.
3. Before making a call, press and hold  or  to select a profile.


**Note:** Once a profile has been selected to use when making a call, the phone will return to the default settings after 30 seconds.

## Changing Menu Settings

**Handset ringer melody** — There are ten ringer melodies.


**Handset ringer volume** — There are five volume levels plus **Off**.

**Tone (“Equalizer”) setting** — There are five tone settings.

**Note:** To adjust tone while making a call, press the  button to access the equalizer setting, press the  or  button to adjust the setting. Press the volume switch on the side of the phone to exit this mode.

**Switch keypad beep on or off** — Turns on or off the keypad beep.

**Change contrast** — There are five screen contrast levels.










**Switch “auto talk” on or off** — The phone will automatically answer a call when the handset is removed from its base when Auto Talk is **ON**. This is the default setting. If Auto talk is **OFF**, press the  button to answer any calls.

**Change backlight timer** — Choose between 10, 20, 30 or 40 seconds until the backlight timer switches off.

**Switch confirmation beep on or off** — There is a beep confirmation when a setting is changed. This can be switched on or off.



**Change language** — There are five display languages available on the handset: **English, German, French, Spanish, and Italian.**

1. Open the menu by pressing , then scroll  or  until **Handset** is highlighted and press .
2. Scroll  until the desired menu setting (see options above) is highlighted and press .
3. The current setting will be displayed.
4. Change the setting using  or  and press .

## Changing Clock Settings








**Change date/time** — Enter the Date and Time settings.

**Change clock to 12- or 24-hour format** — Choose between a standard 12-hour format clock or a 24-hour format (military time).

**Set alarm** — Set an alarm date, time, melody, and reoccurrence.






**Switch night light on or off** — Sets the night light.




**Note: The alarm must be set before the night light feature will work.**

1. Open the menu by pressing , then scroll  or  until **Handset** is highlighted and press .
2. Scroll  until the desired clock setting (see options above) is highlighted and press .
3. The current setting will be displayed.
4. Enter the desired date and/or time setting required (the handset has a 24-hour clock) press .
5. An alarm melody and reoccurrence (**Once, Every Day, Mon to Fri, or OFF**) can be selected after the alarm time is set.










## Changing Base Settings

**Change base ringer melody** — There are ten base ringer melodies.

1. Open the menu by pressing , then scroll  or  until **Base settings** is highlighted and press .
2. **Ring tone** is highlighted, press .

3. The ringer melody setting (e.g. **8**) will be displayed.
4. Change the ringer melody using  or  and press .

**Change base ringer volume** — There are five volume levels plus Off.

1. Open the menu by pressing , then scroll using  or  until **Base settings** is highlighted and press .
2. Scroll  until **Ringer volume** is highlighted and press .
3. The current base ringer volume level (e.g. **5**) will be displayed.
4. Change the base ringer volume using  or  and press .

## Phone book

Up to 200 names with phone numbers can be alphabetically stored in the phone book. To quickly find a phone book entry, simply enter the first letter of the stored name.

**Note: Each phone book entry allows for up to 16 letters for any name and up to 24 digits for any phone number.**




**Important: Enter the area code for each phone number stored.**

## Keypad use for phone book

The keypad contains alpha-numeric keys. Pressing one key multiple times will









scroll through the available letters and numbers which that key represents.

Other useful keys:


- press  for a space
- press  to delete a number or letter entered
- press  to change from upper case (e.g. ABC) to lower case (e.g. abc)













**Note: To enter the same letter twice, enter the letter and then pause until the cursor moves to the next space before entering it again.**

## Enter a name and number in the phone book








1. Open the phone book by pressing .
2. Press . The display will show **New entry**, press  again.
3. Enter the name to store and press .
4. Enter the phone number to store and press .
5. Scroll using  or  to choose a ringer for this entry and press .

## Edit a phone book entry



1. Open the phone book by pressing .







2. Scroll using  or  to find the entry to edit and press .
3. Scroll  to display **Edit entry** and press .
4. Press  to delete characters, use the keypad to enter new ones, press .
5. Press  to delete digits, use the keypad to enter new ones, press .
6. Scroll using  or  to choose a ringer for this entry and press .

## Delete a phone book entry or all entries









1. Open your phone book by pressing .
2. Scroll using  or  to find the entry to delete or highlight any entry to delete all entries.
3. Press  to display either **Delete entry** or **Delete all** and press .
4. Press  to confirm or  to cancel.

## Using quick dial memory buttons








One name (max. 16 characters) and one telephone number (max. 24 digits) can be stored under each of the quick dial memory buttons:  and .

1. Press the  or  quick dial button.
2. Press . The display will show **New entry**, press  again.
3. Enter the name to store using the keypad and press .
4. Enter the phone number to store and press . **Saved** will be displayed.

## Edit a quick dial entry


1. Choose the quick dial entry to edit by pressing either  or .
2. Press . The display will show **Edit entry**, press  again.
3. Press  to delete characters, use the keypad to enter new ones, press .
4. Press  to delete digits, use the keypad to enter new ones, then press . The display will show **Saved**.





## Delete a quick dial entry

1. Choose the quick dial entry to delete by pressing either  or .
2. Press . Scroll  to **Delete entry** and press .
3. Display will show **Delete entry?** Press  to confirm or  to cancel.

## Incoming calls






**Note: you must subscribe to your phone service provider's Caller Display/ Caller ID service for this feature to work.**






Incoming call telephone numbers will appear in the calls list. If the caller's number is stored in the phonebook, the name will be displayed instead. A total of 30 incoming calls can be stored in the calls list (16 letters per name and 24 digits per number). The number of new calls received will be shown in the display with the flashing  icon. If the number does not appear, this is because the caller's identification (Call Line ID) has been withheld by the caller.

Open the calls list by pressing the  button. Scroll through the calls list by pressing  or . To display more information including the date and time of the call, press .









- **WITHHELD NUMBER** – withheld number, or ID information isn't available
- **INTERNATIONAL** – call is from another country or using an internet service
- **PAYPHONE** – caller is calling from a public payphone

## Store numbers from the calls list to the phonebook






1. Press  to open the calls list at the most recent entry.
2. Scroll using  or  to find the entry to store and press .
3. The display will show **Save to phbk**, press .

4. Using the keypad, enter a name for this stored number and press .
5. Edit the number for this name, if needed, and press .
6. Scroll using  or  to choose the ringer for this entry and press .

## Delete a single entry

1. Press  to open the calls list at the most recent entry.
2. Scroll using  or  to find the listed to delete and press .
3. Scroll  until **Delete** is highlighted and press .
4. Confirm or cancel to delete the calls list entry by pressing  or .

## Delete all calls list entries

1. Press  to open the calls list at the most recent entry.
2. Scroll  until **Delete all** is highlighted and press .
3. The display will show **Delete all Calls?** Press  or  to cancel.





# Adding a Handset


**Note: The following features are only available to if an additional handset(s) has been registered to the current phone system.**

## Register a handset


Only register a handset if it has become de-registered from the base or if it was purchased separately.

**Important: make sure any handset is fully charged before registering.**

At the handset:

1. Press and hold  for approx 10 seconds until the display shows **Press and hold Page key.**












At the base:

2. Press and hold  for at least 10 seconds until the display shows **Register.**










## De-register a handset

De-register a handset if too many are currently registered on the phone system, or if the handset develops a fault and needs to be replaced.



## To De-register a handset

1. Open the menu by pressing , then scroll using  or  until **Handset** is highlighted and press .
2. Scroll using  or  until **Registration** is highlighted and press . Then scroll  to highlight **De-register** and press .
3. Enter the PIN code (default PIN 0000) and press .
4. Enter the handset's internal number (e.g. **1**) and press  to confirm.

## Change handset name

1. Open the menu by pressing , then scroll using  or  until **Handset** is highlighted and press .
2. Scroll using  or  until **Handset name** is highlighted and press .
3. Delete the current name by pressing .
4. Enter a new name (up to 12 letters) and press .

## Transfer an external call internally



1. During an external call, press and hold  **INT** until a short beep is heard, then enter the internal call number of the handset to transfer the call to.
2. To accept the call on the receiving handset, press .






**Note: If no one picks up the call being transferred, re-answer the call at the current phone by pressing  $\langle$ INT .**

## Make an internal call

If two or more handsets are registered to the base internal calls between handsets can be made. Each handset will have been allocated a handset number when registered, e.g. **HS1**, **HS2** etc. These calls are free of charge.

1. Press and hold  $\langle$ INT . The display will show **Handset?** Enter the internal call number of the handset desired.
2. To accept the call on the receiving handset, press .
3. End the call by pressing .

## Make a conference call











1. During an external call, press and hold  $\langle$ INT until a short beep is heard, then enter the internal call number of the handset to transfer to.
2. To accept the call on the receiving handset, press .
3. Once the call has been received on the other handset , activate the conference call by pressing and releasing the  button.
4. Place the external call on hold by pressing  $\langle$ INT (if necessary).
5. The conference call will end when  is pressed.

## Copy phone book entries to another registered handset








**Note: Phone books can only be copied to another handset if that handset is registered on the same phone system.**









- A single entry (Copy entry)
- Entries not already on the handset being copying to (Copy append)
- All entries (Copy all)

**Important: when “copy all” is selected, all existing entries on the handset being copied to will be deleted. To prevent this from happening use “Copy append.”**










1. Open the phone book by pressing .
2. Scroll using  or  to find the entry or entries to copy and press .
3. Scroll  to either **Copy entry**, **Copy append**, or **Copy all** and press .
4. Scroll  **INT** or  **R** to highlight the handset number to copy to and press .
5. Pick up the handset where copying entries to and press .

## Copy a profile

1. Open the menu by pressing , then scroll using  or  until **Profile** is highlighted and press .
2. Scroll using  or  until **Profile 1** or **2** is highlighted and press .

3. Scroll using  or  until **Copy** is highlighted and press .
4. Scroll using  **INT** or  until the handset (e.g. **2**, **3** or **4**) to copy the profile to is highlighted, and press .
5. On the copy-to handset, press  to confirm or  to cancel.

## Setting or Changing system PIN code











1. Open the menu by pressing , then scroll using  or  until **Base settings** is highlighted and press .
2. Scroll using  or  until **System PIN** is highlighted and press .
3. Enter the old PIN code (default PIN is 0000) and press .
4. The phone will prompt for a new 4 digit PIN code (entered twice), press .

**Important: Do not change or reset the PIN code unless instructed by customer service.**

## Use on a private branch exchange


If the phone is on an exchange (e.g. dial 9 to get an outside line), calls can be transferred or called back by using the **R** button. Check with the system administrator for system set-up and instructions. Private exchanges are normally used in a business-setting.

### To set the recall time

1. Open the menu by pressing , then scroll using /P or /R until **Base settings** is highlighted and press .
2. Scroll using /P or /R until **Recall** is highlighted and press .
3. The current recall timing setting (e.g. **Short**) will be displayed.
4. Choose the desired recall timing setting (Short or Long) using /P or /R and press .

### Insert a dialing pause

Insert a pause before the dial tone if the system requires an outside line which takes awhile to connect.











To insert a dialling pause, enter the number to reach the outside line and then press  for two seconds. A **P** on the display will show dialing pause is active.

**Note: A dialing pause can be used with a phone number in the phone book.**

## Set the dial mode

There is a choice of two dialing modes: tone and pulse. The default setting is **TONE** and this is the correct setting for use within the United States.




### To change the dial mode

1. Open the menu by pressing , scroll using  or  until **Base settings** is highlighted and press .
2. Scroll using  or  until **Dial Mode** is highlighted and press .
3. The current dial mode setting (e.g. **Tone**) is displayed.
4. Choose the dial mode setting required (Tone or Pulse) using  or  and press .

### Reset to default settings

**Important: Resetting to default will NOT delete phone book entries.**

### To reset to default settings

1. Press  for 10 seconds.
2. Confirm or cancel the reset to default settings by pressing  or .

## Help and support

**Some issues may simply be resolved by disconnecting the power to the unit. In such instances the power to the main base station should be switched off and battery pack in the handset should also be removed for about 20 minutes. After 20 minutes, replace the battery pack and reconnect everything to determine if this has resolved the issue.**

## Troubleshooting guide

### I can't make phone calls

1. Make sure the phone cable is connected properly. Make sure you are using the phone cable that came with your phone.
2. Make sure the base is plugged in, switched on and working.
3. Make sure you are not located too far from the base (the phone should work up to 325 yards outdoors and up to 53 yards indoors).
4. Test the phone line and socket by using another phone.

### I keep losing my connection

1. Make sure you aren't too far from the base (in ideal conditions, it should work up to 325 yards outdoors and up to 53 yards indoors).
2. The base may not be in an ideal location – see Safety Information.

### My handset keeps switching off

1. It may need recharging. So it can charge fully, place your handset on its charger



base for at least 15 hours with the charger base plugged in and working.

2. Replace the rechargeable battery pack. Any replacement battery packs should be the same type as those provided.

## **The phone system isn't responding**

You may need to reset to default settings. Please see page 54.

## **Caller's identification (Call Line ID) isn't working**

1. Check you have this service on your phone line. Please call your network provider.
2. The caller may have withheld their phone number.

## **My handset or base doesn't ring**

Check that the ringer is on.

## **I've got a buzzing noise on my radio, TV, or computer**

We suggest you use your cordless handset at least 3 feet away from electrical equipment and mobile phones.

## **There is interference in the earpiece and/or internet connection is very slow when using the phone**


You must plug the phone into the wall socket via an ADSL filter if you have broadband internet on your phone line.

## Energy efficient power adapter

The included power adapter meets the eco-design requirements of the European Union (Directive 2005/32/EG).



## Disposal

The  symbol on this product indicates that electrical and electronic apparatus and battery pack must be disposed of **separately** from domestic waste at suitable collection points provided by the public waste authorities.

## Technical details

<b>Standard</b>	DECT <sup>1</sup> GAP <sup>2</sup>
<b>Power supply (base station)</b>	Input: 100-240V~50/60Hz 250mA Output: 12VDC 670mA
<b>Range</b>	Outdoors Approx 325 yards/300m Indoors Approx 53 yards/50m
<b>Standby</b>	Up to 100hrs
<b>Maximum Talk Time</b>	Up to 10hrs
<b>Rechargeable battery pack</b>	AAA 2.4V 750mAh NiMH
<b>Dialling mode</b>	Tone (DTMF) Pulse
<b>Optimum ambient temperature</b>	32°F to 113°F (0°C to 45°C)
<b>Optimum relative humidity</b>	20% to 80%
<b>Recall</b>	300, 600 ms

<sup>1</sup> DECT: Digital Enhanced Cordless Telecommunication

<sup>2</sup> GAP: Generic Access Profile = standard for the operation of handsets and base stations from different manufacturers.

## Default settings

Language	English
Handset name	PowerTel
Handset ringing melody (external)	7
Handset ringing melody (internal)	9
Handset ringing volume	5
Base ringing melody	8
Base ringing volume	5
Keypad beep	On
Auto talk	On
Contrast	3
Backlight time	10s
Boost memory	Off
Recall time	600ms
Dialing mode	Tone
PIN code	0000

# Maintenance and Warranty

## Maintenance

- Please clean your equipment's surfaces with a soft, lint-free cloth.
- Never use cleaning agents or solvents.

## Warranty

AMPLICOM equipment is produced and tested according to the latest production methods. The implementation of carefully chosen materials and highly developed technologies ensure trouble free functioning and a long service life. The terms of the warranty do not apply where the cause of the equipment malfunction is the fault of the telephone network operator or any interposed private branch extension system. The terms of the warranty do not apply to the rechargeable battery pack or power packs used in the products. The period of warranty is 24 months from the date of purchase.

All deficiencies resulting from material of production faults which occur during the period of warranty will be eliminated free of charge. Rights to claims under the terms of warranty are annulled following intervention by the purchaser or third parties. Damage caused as a result of improper handling or operation, incorrect positioning or storing, improper connection or installation, Acts of God or other external influence are not covered by the terms of warranty.

In the case of complaints, we reserve the right to repair or replace defect parts or provide a replacement device. Replacement parts or devices become

our property.

Rights to compensation in the case of damage are excluded where there is no evidence of intent or gross negligence by the manufacturer.

If your equipment shows signs of defect during the period of warranty, please return to the sales outlet in which you purchased the AMPLICOM equipment together with the purchase receipt. All rights to claims under the terms of warranty in accordance with this agreement must be asserted exclusively with regard to your sales outlet.

Two years after the purchase of our products, claims under the terms of warranty can no longer be asserted.

## Declaration of conformity

The ETL Listed Mark is an alternative to the CSA and UL marks. ETL Testing Laboratories owned by Intertek Testing Services (ITS) is recognized by OSHA as a Nationally Recognized Testing Laboratory (NRTL). ITS tests products according to nearly 200 safety and performance standards. The ETL Listed Mark is accepted throughout the United States when denoting compliance with nationally recognized standards such as ANSI, IEC, UL, and CSA.



This certification mark indicates that the product has been tested to and has met the minimum requirements of a widely recognized (consensus) U.S. product safety standard, that the manufacturing site has been audited, and that the applicant has agreed to a program of periodic factory follow-up inspections to verify continued conformance.

## A

- Adjusting the handsfree volume 12
- Adjusting the earpiece volume 11
- Alarm 17-18
- Auto talk 16

## B

- Backlight timer 16
- Base ringer melody 18
- Base ringer volume 19
- Base settings 18
- Boost memory 16
- Boosting the earpiece volume 11

## C

- Changing the PIN code 29
- Change case 20
- Charging the battery pack 7
- Check the contents of the box 6
- Conference calls 27
- Connecting the base and charger 6-7
- Contrast 16

## D

- Date/time 17
- Default settings 35
- De-register a handset 25-26
- Dial mode 31
- Dialing pause 30
- Dialing from the phone book 11
- Dialing from a quickdial button 11
- Display icons 8
- Display calls list entries 11

## E

- Earpiece volume 11
- End a call 10
- Entering names in the phonebook 19
- Equalizer 16

## F

- Find a handset 13

**H**

Handset name 26  
Handset ringer melody 16  
Handset ringer on/off 13  
Handset ringer volume 16  
Handsfree 12  
Headset use 12

**I**

Internal calls 27

**K**

Keypad lock 13  
Keypad beep on/off 16

**L**

Language 17

**M**

Making a call 10  
Making internal calls 27  
Mute 12

**P**

Phone book 11, 19, 23  
Profiles 14-15

**Q**

Quickdial 11, 22

**R**

Redial 11  
Register a handset 25  
Reset to default settings 31

**T**

Tone control (see Equalizer)

**U**

Using a headset 12  
Using the menu 16

**V**

Volume 11, 12, 15, 16