



# HandleEasy 321rc

English

Version 1.0

HandleEasy 321rc är en lättskött fjärrkontroll med stora knappar.

## Batterier

HandleEasy behöver tre stycken 1,5 V batterier typ AAA. När batterierna är på väg att ta slut blinkar indikatorn tre gånger efter varje knapptryckning. Använd endast batterier av hög kvalitet. Sätt i batterierna enligt markeringarna för plus- respektive minuspol under luckan på baksidan.

## Programmering av knappar

För att HandleEasy skall fungera till din utrustning behöver den "lära sig" vilka signaler som skickas av utrustningens fjärrkontroll. HandleEasy kan också "lära sig" signaler från flera utrustningars fjärrkontroller, t. ex. kanalbyte från dekoderns och ljudvolym från tevens fjärrkontroller.

1. Håll både **ON** och **OFF** intryckta cirka 3 sekunder. Indikatorn tänds med fast sken (om ingen knapp trycks inom 10 sekunder avbryts inlärningsläget).
2. Tryck önskad knapp på HandleEasy. Indikatorn blinkar en gång.
3. Rikta utrustningens fjärrkontroll mot HandleEasy på ungefär 2-10 cm avstånd och tryck motsvarande knapp. Indikatorn blinkar två gånger på HandleEasy vid lyckad inläring. Vid fel blinkar den 6 gånger. Vid behov, håll utrustningens knapp intryckt upp till 10 sekunder för att lyckas med inläringen.

Gör om steg 2 och 3 för varje knapp eller om inläringen misslyckas.

Gör om steg 1 till 3 om en knapp behöver ändras.

Håll både **ON** och **OFF** intryckta tills indikatorn slocknar för att avsluta inläring eller vänta 10 sekunder.

## Programmering, knapp med dubbelsignal

Vissa fjärrkontroller skickar olika signaler vid varannan knapptryckning, dubbelsignal. Om du märker att HandleEasy endast fungerar ibland eller hoppar dubbla steg är det troligt att originalfjärrkontrollen använder en dubbelsignal. Gör enligt följande beskrivning för att lära HandleEasy denna dubbelsignal.

1. Håll både **ON** och **OFF** intryckta cirka 3 sekunder. Indikatorn tänds med fast sken (om ingen knapp trycks in inom 10 sekunder avbryts inlärningsläget).
2. Tryck önskad knapp på HandleEasy. Indikatorn blinkar en gång.

3. Rikta utrustningens fjärrkontroll mot HandleEasy på ungefär 2-10 cm avstånd och tryck motsvarande knapp. Indikatorn blinkar två gånger på HandleEasy vid lyckad inläring. Vid fel blinkar den 6 gånger. Vid behov, håll utrustningens knapp intryckt upp till 10 sekunder för att lyckas med inläringen.
4. Tryck samma knapp på HandleEasy igen. Indikatorn blinkar en gång.
5. Tryck samma knapp på utrustningens fjärrkontroll igen. Indikatorn blinkar två gånger på HandleEasy vid lyckad inläring. Dubbelsignalen är nu inlärd.

Gör om steg 2-5 för varje knapp med dubbelsignal eller om inläringen misslyckas.

HandleEasy är nu klar för användning.

Håll både **ON** och **OFF** intryckta tills indikatorn slocknar för att avsluta inläring eller vänta 10 sekunder.

## Felsökning

Om HandleEasy endast fungerar ibland eller hoppar dubbla steg måste programmering av dubbelsignal göras. Vid programmering av dubbelsignal måste två inläringar i rad lyckas per knapp för korrekt funktion.

### Misslyckas inläringen trots upprepade försök:

- Prova längre eller kortare knapptryckningar på utrustningens fjärrkontroll (1-10 sekunder).
- Prova olika avstånd och vinklar mellan fjärrkontrollerna.
- Byt batterier i utrustningens fjärrkontroll.

## Declaration of conformity

Doro deklarerar härmed att produkten Doro HandleEasy 321rc överensstämmer med de väsentliga kraven och övriga relevanta bestämmelser i direktiv 1999/5/EG(R&TTE), 2002/95/EG(ROHS). Kopia av tillverkardeklarationen finns på [www.doro.com/dofc](http://www.doro.com/dofc)

## Garanti

Denna apparat har ett års normal varugaranti. Vid eventuell reklamation, tag kontakt med inköpsstället. Garantiservice utförs endast mot uppvisande av giltigt inköpskvitto/fakturakopia. Garantiåtagandet gäller inte om felet beror på olyckshändelse eller därmed jämförlig händelse eller åverkan, inträngande vätska, vanvård, onormalt brukande eller något annat förhållande på köparens sida.

# English

HandleEasy 321rc is an easy-to-use remote control featuring large buttons.

## Batteries

HandleEasy uses three 1,5V AAA batteries. When the batteries are running low, the indicator will flash three times when pressing a button. Only use high quality batteries. Insert the batteries according to the markings for plus and minus terminals under the cover at the back.

## Programming buttons

In order for HandleEasy to work together with your equipment, it must be 'taught' the signals that are sent from the remote control of the equipment. HandleEasy can also be taught the signal of other remote controls from different equipment i.e. channel browsing from the TV and audio volume from the stereo.

1. Keep the **ON** and **OFF** buttons depressed for about 3 seconds. The indicator will show a steady light (if no button is depressed within 10 seconds, the learning mode will be cancelled).
2. Press the desired button on HandleEasy. The indicator will flash once.
3. From a distance of approx. 1 in. to 4 in., point the remote control of the equipment towards HandleEasy (so that the signal points of both remote controls are facing each other) and press the corresponding button. If HandleEasy was successful in learning the signal, the indicator will flash twice. If there is an error, the indicator will flash six times. If necessary hold down the button of the equipment for up to 10 seconds to succeed with the learning.
4. After pairing wait for 10 seconds before testing the programmed button or hold down the **ON** and **OFF** buttons until the indicator goes out.

Repeat steps 2 and 3 for each button, or if the learning fails. Repeat steps 1 and 3 if a button needs to be altered.

## Programming, button with double signal

Certain remote controls send different signals every other time a button is pressed, a double signal. If you experience that HandleEasy only works now and then or jumps double steps it is likely that the original remote control utilizes a double signal. To teach HandleEasy this double signal, follow the instructions below.

1. Keep both **ON** and **OFF** depressed for about 3 seconds. The indicator will show a steady light (if no button is depressed within 10 seconds, the learning mode will be cancelled).
2. Press the desired button on HandleEasy. The indicator will flash once.

3. From a distance of approx. 1 in. to 4 in., point the remote control of the equipment towards HandleEasy and press the corresponding button. If HandleEasy was successful in learning the signal, the indicator will flash twice. If there is an error, the indicator will flash six times. If necessary hold down the button of the equipment for up to 10 seconds to succeed with the learning.
4. Press the same button on HandleEasy once again. The indicator will flash once.
5. Press the corresponding button on the remote control of the equipment once again. If HandleEasy was successful in learning the signal, the indicator will flash twice. HandleEasy has now learned the double signal.

Repeat steps 2 to 5 for each button utilizing a double signal, or if the learning fails. HandleEasy is now ready for operation. Keep both **ON** and **OFF** depressed or wait 10 seconds to exit learning mode.

## Troubleshooting

If HandleEasy only works now and then or jumps double steps, you must program it to utilize a double signal.

Two consecutive learnings per button must be successful, when programming a double signal.

### If learning fails even after repeated attempts:

- Try longer or shorter (1-10 seconds) press of the button on the remote control of your equipment.
- Try different distances or angles between the remote controls.
- Try replacing the batteries in the remote control of the equipment.

If you cannot resolve the fault using the faultfinder section, technical support is available by email on [tech@doro-uk.com](mailto:tech@doro-uk.com) or via a **premium rate telephone number: 0905 895 0854**, calls cost **50 pence per minute** (prices correct at the time of publication). Further contact details are available on our website: [www.doro-uk.com](http://www.doro-uk.com)

Alternatively you can write to:

Customer Services, Doro UK Ltd, 1 High Street,  
Chalfont St Peter, Buckinghamshire SL9 9QE

## **Declaration of conformity**

Doro hereby declares that the Doro HandleEasy 321rc product conforms to the essential requirements and other regulations contained in the directives 1999/5/EC (R&TTE), 2002/95/EC (ROHS). A copy of the manufacturer's declaration is available at [www.doro.com/dofc](http://www.doro.com/dofc)

## **Guarantee**

This product is guaranteed for a period of 12 months from the date of purchase. If you experience any problems please contact the place of purchase. Proof of purchase is required for any service or support needed during the guarantee period. This guarantee shall not apply to batteries or any fault caused by an accident or a similar incident or damage, liquid ingress, negligence, abnormal usage or any other circumstances on the purchaser's part.