




Serene VM-150

Amplified Answering Machine



- Loud and clear message playback
- Selectable slow playback speeds
- Easy set up, just plug and play right out of the box with pre-recorded Greeting. Forty minutes of recording time, remote access, toll saver and more

Hear More, Understand Better

This answering machine is ready for you with these settings:

- Pre-recorded greeting message
- Answers after 4 Rings
- Flashing indicator for new messages

Turn on Answering Machine:

Press ON/OFF to turn on or off the answering machine.

(**Note:** If the digital indicator is flashing, it shows the number of new messages; if it's not flashing, it shows the number of old messages and no new message. "- -" on the indicator means it is off.)

To play new or old message:

1. Press PLAY to play message
2. Press VOL+ or VOL- to adjust volume.

Slow down a message:

Press SLOW to slow down the message to Slow 1, press again for Slow 2, or again for Normal speed.

Repeat a message:

To repeat the current message, press REPEAT once. To go to the previous message, press REPEAT twice.

Skip a message:

To skip to the next message, press SKIP

Delete one or all messages:

During message play back, press DELETE to delete the message. While in standby, press and hold DELETE for 3 seconds to delete all old messages.

(**Note:** New messages cannot be deleted until they have been heard.)

To intercept a call:

1. While someone is leaving you a message, press CALL INTERCEPT and start talking. Press it again to hang up.
2. To mute, press SET-TIME. To un-mute, press SET-TIME once again.

Customizing a new Out-Going Message (OGM):

1. Press and hold the OGM for 3 seconds. It will announce, "To record new OGM, please speak after the tone.
2. Speak clearly and it will allow you to record up to 30 seconds. Press STOP when finished.

**Need Help? Call Toll-free Help Line:
866-376-9271 (9AM-5PM PST, M-F)**