

# Installation and Operating Instructions

## *CO Detector with transmitter*

Model COT-SS

### **Installation**

See the separate manual supplied with your co detector for mounting instructions.

### **Operation**

1. The COT-SS is powered by 120VAC.
2. The COT-SS will sense dangerous concentrations of carbon monoxide (CO) when the preset limit is exceeded.
3. When the COT-SS is activated the Red LED on the face of the transmitter lights up. The transmitter then sends a signal to any Silent Call Signature Series receiver and activates the Receiver.
4. Transmission range is determined by which Signature Series receiver you are using.

### **Address Switch Settings**

The Silent Call system is digitally encoded. All Silent Call receivers and transmitters are tested and leave the factory programmed to a factory default address. ***You do not need to change the address unless someone in your area has Silent Call products and they are interfering with your equipment.***

1. Make sure that all Silent Call transmitters in the area are turned off.
2. Unplug the CO detector from the wall outlet. Note that you MUST unplug the unit from the outlet first or the switch setting will not take effect.
3. Located on the back of the transmitter case is a removable access panel. Remove the access panel. Locate the address switch on the transmitter circuit board that has 5 small dip switches. Set the switches to any combination that you want. For Example: 1, 2 ON 3, 4, 5 OFF. This gives your transmitter an “address”. Note: Do NOT set the switches to the all “ON” or all “OFF” position.
4. Replace the access panel and plug the CO detector into the wall outlet.
5. Refer to your specific Signature Series Receiver instruction manual for programming your receiver to your newly changed transmitter address.

### **Technical Support**

For technical support on this or any other Silent Call product, please feel free to contact us. You can reach us by phone at 800-572-5227 (voice or TTY) or by Email at [support@silentcall.com](mailto:support@silentcall.com)

### **Limited Warranty**

Your transmitter is warranted to be free of defects in material and workmanship for five years from the date of initial purchase. During that time, the unit will be repaired or replaced free of charge when shipped prepaid to Silent Call Communications. This warranty is void if the defect is caused by customer abuse or neglect.



5095 Williams Lake Road, Waterford Michigan 48329

(800) 572-5227 v/tty (248) 673-7360 fax

Website: [www.silentcall.com](http://www.silentcall.com) Email: [silentcall@silentcall.com](mailto:silentcall@silentcall.com)