


Telephone ring amplifier



# DESCRIPTION

## Description

---



# INSTALLATION

## **Important Safety Instructions**

---

When using your device equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:


1. Do not use this product near water, for example, near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
2. Avoid using a device (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
3. Do not use the device to report a gas leak in the vicinity of the leak.
4. Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

**SAVE THESE INSTRUCTIONS!**

# INSTALLATION

## Installation (See drawing)

---



- 1) Insert 4 AA batteries into the battery compartment, for battery backup feature. Test batteries every year.
- 2) Connect the Phone cable to the line jack found at the rear of the Amplicall 10. Connect the other end of the cable to the on the wall.
- 3) Connect the telephone line cord from your telephone into the jack found at the rear of the Amplicall 10.
- 4) Plug the power cable into the power adapter jack found at the rear of the Amplicall 10. Plug the adaptor into the mains supply at the wall (optional)

# INSTALLATION

## Alarm Operation

---

### 1 - SETTING THE ALARM MODE

Choose which alarm mode you want by moving the alarm mode switch to one of the following positions:

0 : no alarm

 : both strobe flasher and sound alarm activated



 : both strobe flasher and shaker (if connected)

 activated

 : both sound alarm and shaker (if connected)

 activated

### 2 - VOLUME CONTROL SLIDE SWITCH

Set the volume of the alarm sound or power on/off.

### 3 - TONE CONTROL SWITCH (3 POSITIONS)

Set the tone of the alarm sound.

# INSTALLATION

## Wall Mounting

---

1. Drill two holes horizontally, 96mm apart, and leave the screws protruding from the wall by 5mm.
2. Hang the base on to the two screws and pull the base down to lock it into place.

## Table Mounting

---

If you want to mount the unit on a table, simply place it in the base cradle, and place the base cradle on the table.

## Change The Battery

---

The unit requires 4xAA batteries

1. Open the battery compartment door.
2. Insert 4 x AA batteries into the battery compartment.
3. Snap the battery compartment door back into place.

**Note:** when the red LED indicator flashes, it is time to replace the batteries.

When replacing the batteries, disconnect all telephone line cords from the modular wall jacks.

## Second Amplicall 10

---

Another Amplicall 10 can be added to the system (call 1-888-864-2446). Add the second piece on one second PTT socket.

# INSTALLATION

## Trouble shooting

---

Symptom	Solution
No incoming call yet the Amplicall10 rings automatically or rings continuously; the shaker vibrates automatically or continuously; the strobe LED flashes automatically.	<ol style="list-style-type: none"><li>1) Check the batteries are inserted correctly.</li><li>2) Check the power adaptor is connected correctly.</li><li>3) Turn off the power switch for 10 minutes and then turn it on.</li></ol>
The red low battery LED flashes automatically.	<ol style="list-style-type: none"><li>1) Replace the batteries.</li><li>2) Turn off the power switch for 10 minutes and then turn it on.</li></ol>
When there is an incoming call but no ringing can be heard.	<ol style="list-style-type: none"><li>1) Check it is connected to the power adaptor correctly.</li><li>2) Check the batteries are installed correctly.</li><li>3) Check if the volume switch is switched on.</li><li>4) Check it is connected to the line cord correctly.</li></ol>

# INSTALLATION

<p>When there is an incoming call but the shaker doesn't vibrate.</p>	<ol style="list-style-type: none"><li>1) Check it is connected to the shaker correctly.</li><li>2) Check the shaker socket to see if it has been damaged.</li><li>3) Check the alarm mode selection switch position is correct.</li></ol>
---	---

# REGULATORY COMPLIANCE

- This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product identifier in the format US:AAAEQ##TXXXX. If requested, this number must be provided to the telephone company.
- All applicable certification jacks Universal Service Order Codes (USOC) for the equipment is provided (i.e. RJ11C) in the package with each piece of approved terminal equipment.
- A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirement adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.
- The REN is useful to determine the quantity of devices you may connect to your telephone line and still have all of those devices ring when your telephone number is called. In most, but not all areas, the sum of the REN's of all devices connected to one line should not exceed five (5.0). To be certain of the number of devices you may connect to your line, as determined by the REN, you should contact your local telephone company to determine the maximum REN for your calling area.
- If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required.

# REGULATORY COMPLIANCE

But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your rights to file a complaint with the FCC if you believe it is necessary.

- The telephone company may make changes in its facilities, equipment, operation or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

- This equipment may not be used on coin service provided by the telephone company. Connection to party lines is subject to state tariffs. This equipment is hearing aid compatible.

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE :** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. Some cordless telephones operate at frequencies that may cause interference to nearby TV's and VCR's; to minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV or VCR; and, if interference is experienced, moving the cordless telephone farther away from the TV

# REGULATORY COMPLIANCE

or VCR will often reduce or eliminate the interference. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

- If trouble is experienced with this equipment, for repair or warranty information, please contact our customer service staff at: 1-888-864-2446

If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

- Please follow instructions for repairing if any; otherwise do not alter or repair any part of device except as specified.

**Opening the equipment or any attempt to perform repairs will void the warranty. For service or repairs, call 1-888-864-2446.**

# REGULATORY COMPLIANCE

- Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation for information.
- If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this telephone equipment does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.
- This equipment is hearing aid compatible.

# GUARANTEE

Sonic Alert warrants the phone against any defect in materials or workmanship for the period of one year from the date of purchase.

Should you experience a problem, contact our customer service department. Be sure to save your sales receipt as proof of purchase date should you need warranty service.

Within a period of one year from purchase date, Sonic Alert will repair or replace (our discretion) your phone at no cost, if a defect in materials or workmanship is found. If we elect to replace your phone, we may replace it with a new or reconditioned product of the same or similar design.

Repair or replacement will be warranted for a period of 90 days or the original time on the original warranty, whichever is longer.

The warranty does not cover accidents, negligence or breakage to any parts. This includes shipping damage, failure to follow instructions, misuse, fire, floods, use of incompatible accessories, Acts of God or failure in your phone service carrier's line service. The product must not be tampered with or taken apart by anyone who is not an authorized Sonic Alert representative. Tampering with the phone will void ant written or implied warranties Sonic Alert shall not be responsible for loss of time, inconvenience, property damage caused by your phone or any other accidental or consequential damages. Warranty service is available only with proof of purchase.

# GUARANTEE

Simply send the Amplicall10(postpaid) and a copy of your sales slip as proof of purchase to:

**Sonic Alert Warranty Center 1081 West Innovation Dr.  
Kearney, MO 64060**

IMPORTANT : YOUR RECEIPT IS PART OF YOUR WARRANTY AND MUST BE RETAINED AND PRODUCED IN THE EVENT OF A WARRANTY CLAIM



## SonicAlert

Sonic Alert Warranty Center  
1081 West Innovation Dr.  
Kearney, MO 64060

Sales: 248-577-5400 Fax: 248-577-5433  
Customer Service & Warranty: 1-888-864-2446