

Setup guide



A1600 DECT 6.0
Amplified Cordless
Freedom Deluxe Phone



ClearSounds 1-800-965-9043

1 Unpack

Please see the Quick Start Guide for information about controls



Telephone handset



A1600 base station



Telephone cord



AC power adapter assembly



Three rechargeable AAA NiMH batteries



Carrying clip



Operating manual and Quick start guide. Please refer to these guides for additional instructions.

2 Power


Plug in




To AC outlet

To phone jack

Charge









1.








2.











Prior to use, charge for 24 hours.

3 Call

	Place	Answer	End
	<ol style="list-style-type: none"> Dial . Press . 	 <ol style="list-style-type: none"> Lift Press . 	Press  .


	Place	Answer	End
	<ol style="list-style-type: none"> Press . Dial . 	Press  .	Press  .

4 Volume

	Adjust	Amplify	Maximum
	 <ol style="list-style-type: none"> Volume DOWN   Volume UP  	 <p>AMP</p>	 <ol style="list-style-type: none">   +5  <p>AMP</p>

	Adjust	Press to adjust ringer volume (or speakerphone volume during calls).
		 <p> </p>







5 Messages










If you prefer to retrieve your messages by using voicemail through your telephone service provider, do not turn on the answering machine.

To retrieve your messages using the ClearSounds A1600 answering machine, take these steps. (Use the base).

Turn on the answering machine

- Menu 
-  to TAM setup, Select 
- Select 
-  to ON, Select 

Record your outgoing message

- Menu 
-  to TAM setup, Select 
-  to Outgoing Msg, Select 
-  to Record OGM, Select 
- After the tone, speak to record, End 