

WARRANTY

Ameriphone will repair or replace your Super Phone-Ringer for one year from the date of purchase if the unit is defective in workmanship or materials. Proof of purchase is required.

All applicable implied warranties, including the implied warranty of merchantability and fitness for a particular purpose, given to you by law are hereby limited in duration of this warranty. **UNDER NO CIRCUMSTANCES WILL AMERIPHONE BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.**

You may also have other warranty rights which vary from state to state.

SUPER PHONE-RINGER Model SR-100

OPERATING INSTRUCTIONS

Thank you for selecting this product from Ameriphone. Your Super Phone-Ringer is manufactured to exact performance, durability and quality standards to provide you years of convenient and trouble free service.

Please read this guide before connecting or using your Super Phone-Ringer and retain this guide for future reference.

OUT OF WARRANTY SERVICE

After the one year warranty period Ameriphone will repair or replace parts for your unit at a minimal charge. Contact our service department for details.

YOUR SATISFACTION


Your satisfaction with our product is very important to us. We would like to know what you like and what you don't like about this product and what we can do to make this product even more beneficial to you. Please give us your comments by calling our Customer Service Department toll free at (800) 874-3005 VOICE, or (800) 772-2889 TTY. We value your comments and thank you again.

INSTALLATION

1. Unplug the telephone line from your telephone.



2. Plug the telephone line into the LINE jack of the Super Phone-Ringer.




FCC REQUIREMENTS

Before connecting the Super Phone-Ringer to your telephone, notify your local telephone company of your intent to use this product. They may ask you for the Federal Communication Commission (FCC) Registration Number and the Ringer Equivalence Number (REN) of the Super Phone-Ringer. Such information is printed on the label at the back of the unit.

Your local telephone company is required by the FCC to allow you to connect FCC registered telephone equipment to their telephone lines. Your notification helps your local telephone company continue to provide the best possible service.

© Ameriphone Inc.5240-1521 SR100 ▲ M18099 11/99

3. Connect one end of the cord provided with the unit into the PHONE jack of the Super Phone-Ringer and the other end into the jack of your telephone.



SUPER PHONE-RINGER

Model SR-100

Operating Instructions



AMERIPHONE®
Helping people communicate easier

12082 Western Avenue
Garden Grove, CA 92841
(714) 897-0808 VOICE
(714) 897-1111 TTY (714) 897-4703 FAX
E-mail: ameriphone@ameriphone.com
<http://www.ameriphone.com>

MOUNTING

The Super Phone-Ringer can be mounted on any wall using the screws or double sided tape provided with the unit.

OPERATION

VOLUME CONTROL

Adjust ringer volume to the most desirable level by sliding the control switch to the HI, MID, LOW or OFF position.

TONE CONTROL

The ringing tone can be adjusted to best suit your hearing by sliding the tone control switch.