

Installation and Operating Manual

CO Detector with Strobe

Model CO2-L

General

1. The CO2-L will sense dangerous concentration of carbon monoxide (CO). When the preset limit is exceeded, the unit will activate the strobe light

Operation

1. Plug the CO2-L power supply into a 120 VAC power outlet.
2. Press and hold the test pushbutton on the Carbon Monoxide Detector.
3. Verify that after a short delay the detector beeps once and within seconds beeps rapidly and the strobe flashes.

Technical Support

For technical support on this or any other Silent Call product, please feel free to contact us. You can reach us by phone at 800-572-5227 (voice or TTY) or by Email at support@silentcall.com

Limited Warranty

Your CO2-L is warranted to be free of defects in material and workmanship for five years from the date of initial purchase. During that time, the unit will be repaired or replaced free of charge when shipped prepaid to Silent Call Communications. To obtain warranty service, contact Silent Call to obtain a return material authorization. This warranty is void if the defect is caused by customer abuse or neglect.



5095 Williams Lake Road, Waterford Michigan 48329
(800) 572-5227
<http://www.silentcall.com>